

SF6 Gas Purity Analyzer

Weshine® Sulfur hexafluoride gas comprehensive tester (also known as: SF6 Gas Purity Analyzer) is a special test instrument for measuring gas purity. It adopts the "electrolysis method" measurement principle, compact structure, easy operation, equipped with ARM technology, full automatic real-time Measurement, monochrome



LCD display measurement data, friendly and beautiful interface, easy to operate, easy to carry.



Main Advantages of the Weshine® SF6 Gas Purity Analyzer.

- Long-life detection components
- Integrate a variety of measurement methods to meet different measurement requirements.
- Large LCD display, English menu, touch screen for easy operation.
- Users can perform calibration on site, thus ensuring reliable use in the field.
- Synchronous display of various data.
- Mass data storage.

Weshine Electric Manufacturing Co., Ltd.

Address: Diangu Technology Center, No. 3088, Lekai North Street

Tel: +86-312-3188565

Phone: +86-18731260588

E-mail: sale09@weshineelectric.com

Weshine® SF6 Gas Purity Analyzer Parameter (Specification)

PRODUCT INFORMATION			
Product Name	VS-9601 SF6 Gas Purity Analyzer		
Typical Application	Measuring the SF6 gas purity in circuit breakers and GIS.		
Measurement Range	Purity 0 % to 100 %	Model Number	VS-9601
Flow	0.5 L (101.2 kPa)	Working Time	> 10 hours
Power Supply	AC220 V	Resolution	250 x 100 x 300 mm
Weight	4 kg	Certificates	CE; EMC; LVD; ISO; IEC;

The **SF6 Gas Purity Analyzer** is mainly used to measure the gas purity of SF6 gas and SF6/N2 mixed gas. It can also be used in applications where several gases are present, if specifically requested by the user. There are battery charging indicator and power indicator on the SF6 purity tester. When charging, just connect to AC220V. The **SF6 Gas Purity Analyzer** has a built-in charger with overcharge and overdischarge protection. The detection component can quickly and accurately measure the purity of SF6, and its life can be up to ten years un.

Quality Certificates

We always believe that all the success of our company is directly related to the quality of the products we provide. VS-9601 **SF6 Gas Purity Analyzer** meet the highest quality requirements specified in ISO9001, ISO14000:14001 guidelines and our strict quality control system.



Weshine Electric Manufacturing Co., Ltd.

Address:Diangu Technology Center, No. 3088, Lekai North Street

Tel:+86-312-3188565

Phone:+86-18731260588

E-mail:sale09@weshineelectric.com

Shipment



For further information on Weshine's Service Solutions, contact our 24/7 online sales representative to get quotes from Weshine.

Contact us

FEEL FREE TO MAKE A PHONE CALL:400 996 1868	OR E-MAIL TO: info@weishengelectric.com
SALES OFFICE Weshine Limited 602, Building 3, Diangu Technology Center, No. 3088, Lekai North Street W/app: +86 1873 1260 588 E. info@weishengelectric.com sale01@weishengelectric.com	CONTACT OFFICE T. 0312 3188565 E. bdweisheng@weishengelectric.com AFTER-SALES SERVICE T. +86 157 1252 6062